



# Windows 10 Installation Guide

Complete Step-by-Step Visual Tutorial



## Aim

---

**Objective:** To install Windows 10 Operating System on a computer system with complete understanding of the installation process, requirements, and post-installation configuration.



# System Requirements



## Processor

**1 GHz or faster**

Compatible with 64-bit or  
32-bit processor



## RAM Memory

**2 GB (64-bit)**

1 GB for 32-bit systems



## Storage Space

**20 GB or more**

For 64-bit installation



## Graphics Card

**DirectX 9+**

WDDM 1.0 driver



## Display

**800x600 resolution**

Minimum screen size



## Internet

**Required**

For updates & activation



# Prerequisites - Before Installation

## Pre-Installation Checklist

- Backup all important data** - Save files to external drive or cloud storage
- Windows 10 ISO file** - Downloaded from Microsoft official website
- Bootable USB drive** - Minimum 8GB USB flash drive
- Product Key** - Valid Windows 10 license key (if required)
- Device Drivers** - Download essential drivers beforehand
- Stable Power Supply** - Ensure uninterrupted power during installation



# Creating Bootable USB Drive

## 1 Download Media Creation Tool

Visit Microsoft's official website and download the Windows 10 Media Creation Tool. This free tool will help create a bootable USB drive.

## 2 Run Media Creation Tool

Launch the tool with administrator privileges. Accept the license terms when prompted.

## 3 Choose "Create installation media"

Select the option to create installation media (USB flash drive, DVD, or ISO file) for another PC.

## 4 Select Language, Edition, and Architecture

Choose your preferred language, Windows 10 edition (Home/Pro), and architecture (64-bit recommended).

## 5 Choose USB Flash Drive

Select your USB drive from the list. Warning: All data on the USB will be erased!



## Windows 10 Installation Process

1

### Insert Bootable USB and Restart

Insert the bootable USB drive into your computer and restart the system. The computer needs to boot from the USB drive.

2

### Enter BIOS/UEFI Settings

Press the BIOS key during startup (usually F2, F12, DEL, or ESC - depends on manufacturer). Change boot priority to boot from USB first.



## Installing Windows 10 from bootable USB

Step 01: Plug in the bootable USB in to system unit.

Step 02: Restart the computer.

Step 03: In some computers you need to change BIOS boot sequence, to do this:

- Access BIOS setup by pressing setup key continuously at restart
- Set USB as first bootable device in boot sequence.
- Save changes and exit the setup.

In other computers you just need to access boot order and select the bootable USB.

*Note: Setup key on different computer vary, some of the possible keys are: Esc, Del, F2, F10)*

Step 04: Computer now loads windows files from USB.

Step 05: Click Install Now to start.

Phoenix - AwardBIOS CMOS Setup Utility  
Advanced BIOS Features

Hyper-Threading Technology [Enabled]  
Quick Power On Self Test [Enabled]  
First Boot Device [USB-HDD]  
Second Boot Device [HDD-0]

Item Help

Menu Level ▶

Third Boot Device  
Boot Other Device  
Boot Up Floppy Se  
Security Option  
OS Select For DRA

First Boot Device

Select Your Boot  
Device Priority

- |             |       |     |   |
|-------------|-------|-----|---|
| HDD-3       | ..... | [ ] | ▲ |
| ZIP100      | ..... | [ ] |   |
| USB-FDD     | ..... | [ ] |   |
| Card Reader | ..... | [ ] |   |
| USB-CDROM   | ..... | [ ] |   |
| USB-HDD     | ..... | [*] |   |
| LAN         | ..... | [ ] |   |
| Disabled    | ..... | [ ] | ▼ |

↑↓:Move ENTER:Accept ESC:Abort

↑↓←→:Move Enter:Select +/-:PU/PD:Value F10:Save ESC:Exit F1:General Help  
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Figure 1.2: Setting USB as first bootable device in BIOS

## Boot Manager

### Boot Option Menu

**USB Hard Drive (UEFI) - KingstonDataTraveler G3 (KingstonDataTraveler G3)**

**OS boot Manager (UEFI) - Windows Boot Manager (KINGSTON SUV400S37240G)**

**Boot From EFI File**

**I and ↓ to change option, ENTER to select an option.**

**Press F10 to BIOS Setup Options, ESC to exit.**

*Figure 1.3: Selecting boot from USB-HDD*



*Figure 1.4: Step 05 – Click to install windows*

Step 06: Enter Windows 10 product key and press Next (if available).

Step 07: Check “I accept the license terms to agree” and press Next.

Step 08: Click “Custom: Install Windows only (Advanced)”.

Step 09: Select and remove all partitions from the Disk.




Figure 1.5: Step 08 – Click Custom Install for fresh installation

Step 10: Select unallocated space and click New, specify the size in MBs for new partition.

Step 11: Similarly create other partitions.




Figure 1.6: Step 09, 10 & 11 – Deleting and creating partitions

Step 13: The setup will now be copying files and installing the windows (this may take several minutes depending on your system configuration).



Figure 1.7: Step 09, 10 & 11 – Copying files and installing windows

Step 14: After the installation is completed, the computer will reboot.

Step 15: Remove the USB from the computer.

Step 16: The setup will now be getting the device ready to use.



*Figure 1.8: Step 16 – Getting device ready*

Step 17: Click the "Use Express Setting" to use default settings.

Step 18: Skip the Microsoft account login.

Step 19: Create your user account by providing the username and password.




Figure 1.9: Step 19 – Creating user account

Step 20: Wait until the setup configures the setting and installs the default Apps.

Step 21: The setup has successfully installed windows 10 and the desktop appears.




Figure 1.10: Step 21– Windows 10 desktop